

Mounting Bracket Kit: Kick-Down Jacks

Application: For mounting Kick-Down Jacks on the REAR OF CHEVY P30 chassis beginning in 1993 with GVWR's OF 14,500#, 14,800# and 16,000# and the REAR OF WORKHORSE P chassis with a GVWR BETWEEN 14,800# and 17,000#. Rear bracket.

Mfr. #: AP0921 Bracket Kit Chevy/Workhorse Rear

Includes: 1 - AP0910 Bracket Left Rear
1 - AP0911 Bracket Right Rear
1 - AP0922 Hardware Kit

M.S.R.P.: See Item Price Listing

NOTE : EXHAUST PIPE MAY NEED TO BE MOVED TO COME OUT IN FRONT OF REAR AXLE. HAVE COACH OWNER TAKE COACH TO A PROFESSIONAL MUFFLER SHOP. JACKS, HYDRAULIC LINES, AND WIRES MUST BE PROTECTED FROM EXHAUST PIPE HEAT.

