


NOTE: INSTALLATION MUST CONFORM TO GOOD SHOP PRACTICES, SAE STANDARDS, RVIA STANDARDS, AND OTHER APPLICABLE STANDARDS.



LED # LED 1 LED 2 LED 3 LED 4 LED 5 LED 6 LED 7 LED 8 LED 11 LED 12 LED 15 LED 16 LED 19 LED 21	COLOR YELLOW RED YELLOW	DESCRIPTION RR COIL RR CONTACT LR COIL LR CONTACT RF COIL RF CONTACT LF COIL LF COIL DUMP COIL DUMP CONTACT PUMP CONTACT PUMP CONTACT LOWN COIL REQ VALVE COIL LF WARN SW
LED 26 LED 29 LED 30 LED 31 LED 32 LED 33 LED 34 LED 35 LED 36 LED 37 LED 38 LED 39 LED 40	RED RED YELLOW GREEN RED GREEN RED RED RED RED RED RED RED RED	RF PRESS SW NOT USED NOT USED NOT USED MASTER WARNING CONTROL 50 LB PSW INPUT JACK INTERRUPT PARK BRAKE BOARD ENABLED ACCESSORY IN ACCESSORY OUT LINK LIGHT EQ VALVE CONTACT

FUSE F1 F2 F3 F4 F6 F8 F10 *F11 *F13	RATING 15 AMP 15 AMP 15 AMP 15 AMP 5 AMP 5 AMP 7.5 AMP 3 AMP 10 AMP	DESCRIPTION RR OUTPUT LR OUTPUT RF OUTPUT LF OUTPUT DUMP PUMP OUTPUT ACC INPUT WARN LITE SUPPLY ACC OUTPUT EQ VALVE
---	---	---

NOTE: COMPONENTS MARKED WITH A "*" ARE LOCATED ON OLDER 325 BOARD ASSEMBLIES.

ON NEWER BOARD ASSEMBLIES, FUSES F11 AND F12 HAVE BEEN REPLACED BY POLYFUSES. THESE POLYFUSES ARE NOT REPLACEABLE.

NOTE: INSTALLATION MUST CONFORM TO GOOD SHOP PRACTICES, SAE STANDARDS, RVIA STANDARDS, AND OTHER APPLICABLE STANDARDS.