



NOTE: PINS NOT NOTED ARE UNUSED

- PIN
1. BLK(W8600) PUMP CONTROL
 2. BLK(W7698) WARN/ALARM CONTROL
 3. BLK(W3000) RR WARNING SWITCH
 4. BLK(W4400) LR SOLENOID VALVE
 5. BLK(W3400) RR SOLENOID VALVE
 6. BLK(W4000) LR WARNING SWITCH
 7. WHT(W6230) GROUND
 8. RED(W6100) BATTERY
 9. RED(W6100) BATTERY
 10. BLK(W8101) 50 LB PRESS SWITCH
 11. BLK(W9000) PARK BRAKE
 12. RED(W6110) IGNITION
 13. RED(W6120) ACCESSORY

NOTE: INSTALLATION MUST CONFORM TO GOOD SHOP PRACTICES, SAE STANDARDS, RVIA STANDARDS, AND OTHER APPLICABLE STANDARDS.

NO.	DATE	REVISION

HWH 1-80 EXIT 267 SOUTH
 RT 1 MOSCOW, IOWA 52760
 SCALE 1:3 DATE 31MAY12 DRAWN BY
SYSTEM SCHEMATIC ELEC

THE INFORMATION DISCLOSED ON THIS DRAWING IS CONFIDENTIAL AND MUST NOT BE DISCLOSED OR USED IN ANY MANNER WHICH WILL BE DETRIMENTAL TO THE HWH CORPORATION

DRAWING NUMBER
MP907880