HWH® AP43076 Leveleze® Indicator Light System for Hydraulic Switch Valves



Leveleze® Indicator Light System makes leveling easy. Avoid the confusion of looking at a level-bubble to figure which side or end of the trailer needs to be leveled.

- 1. You simply position the hydraulic switch as indicated by the "ON" light.
- 2. Activate pump switch until indicator light goes off. The microprocessor in the sensing unit will then direct you with next operation.
- 3. When all the lights are out the vehicle is level.



(On I-80, Exit 267 South) | 2096 Moscow Road | Moscow, Iowa 52760 **Phone:** (800)321-3494 or (563)724-3396 | Fax: (563)724-3408 | Web: www.HWH.com Made in the USA