


# HWH COMPUTER-CONTROLLED HYDRAULIC LEVELING SYSTEM WITH STRAIGHT-ACTING JACKS

**CAUTION:** READ AND UNDERSTAND ENTIRE OPERATOR'S MANUAL, INCLUDING CAUTIONS, BEFORE OPERATING. THIS SHEET IS FOR QUICK REFERENCE ONLY.

## AUTOMATIC LEVELING

1. TURN IGNITION SWITCH TO THE "ACC" OR "'ON" POSITION. TRANSMISSION SHIFT MUST BE IN POSITION FOR PARKING. PARK BRAKE MUST BE SET EITHER MANUALLY OR AUTOMATICALLY. IF "NOT IN PARK/BRAKE" LIGHT IS ON, CHECK SHIFT AND BRAKE POSITION.
2. PRESS "I", THE HYDRAULIC OPERATION INDICATOR LIGHT WILL COME ON STEADY.
3. PRESS "I" SECOND TIME, THE INDICATOR LIGHT WILL FLASH. THE COACH WILL LEVEL THEN THE SYSTEM WILL TURN OFF.



(CONTINUED)

ML9279/MP35.9917  
25JUL97

---

# HWH COMPUTER-CONTROLLED HYDRAULIC LEVELING SYSTEM WITH STRAIGHT-ACTING JACKS (CONTINUED)

---

## STORE OPERATION

1. TURN IGNITION TO "ACC", "ON" OR START ENGINE.
2. PRESS "I" ONCE. THE INDICATOR LIGHT WILL COME ON STEADY.
3. PRESS "STORE", STORE INDICATOR LIGHT WILL FLASH, JACKS WILL RETRACT.
4. WHEN "TRAVEL" LIGHT IS ON AND THE JACKS ARE FULLY RETRACTED, THE COACH MAY BE MOVED. SYSTEM WILL SHUT ITSELF OFF.

**IMPORTANT:** DO NOT INTERRUPT POWER TO THE SYSTEM UNTIL THE SYSTEM AUTOMATICALLY SHUTS ITSELF OFF.

## MANUAL OPERATION

1. TURN IGNITION SWITCH TO THE "ACC" OR "ON" POSITION. TRANSMISSION SHIFT MUST BE IN POSITION FOR PARKING. PARK BRAKE MUST BE SET EITHER MANUALLY OR AUTOMATICALLY. IF "NOT IN PARK/BRAKE" LIGHT IS ON CHECK SHIFT AND BRAKE POSITION.
2. PRESS "I", INDICATOR LIGHT WILL COME ON STEADY.

ON THE RIGHT HAND PORTION OF THE TOUCH PANEL NOTE THE OUTLINE OF A COACH AND THE VARIOUS RAISE (UP ARROW) AND THE LOWER (DOWN ARROW) TOUCH BUTTONS.

3. PRESS THE RESPECTIVE RAISE (UP ARROW) BUTTON TO RAISE THE RESPECTIVE SIDE OR END OF THE COACH. A YELLOW LIGHT TO THE FRONT, SIDE OR REAR OF THE COACH OUTLINE INDICATES THAT SIDE OR END IS LOW. THE LOWER (DOWN ARROW) BUTTONS WILL LOWER THE COACH.

NOTE: JACKS WILL ALWAYS WORK IN PAIRS, FRONT, RIGHT SIDE, LEFT SIDE, OR REAR.

## ROOM EXTENSIONS

**IMPORTANT:** IF THE VEHICLE IS EQUIPPED WITH A ROOM EXTENSION, READ THE OWNERS MANUAL FOR INSTRUCTIONS ON USING AND OPERATING THE ROOM EXTENSION.