


ORIENTATION  
FRONT



LOCATION AND ORIENTATION OF PUMP/MANIFOLD ASSEMBLY WILL DIFFER DEPENDING UPON DEM.

- Ⓐ AP7385 HOSE ASSY 04 x 252' - RF RODD END
- Ⓑ AP42093 HOSE ASSY 05 x 276' - RF CAP END
- Ⓒ AP5561 HOSE ASSY 04 x 336' - LF RODD END
- Ⓓ AP8381 HOSE ASSY 05 x 360' - LF CAP END
- Ⓔ AP4159 HOSE ASSY 04 x 72' - RR RODD END
- Ⓕ AP42051 HOSE ASSY 05 x 84' - RR CAP END
- Ⓖ AP5352 HOSE ASSY 04 x 96' - LR RODD END
- Ⓗ AP42054 HOSE ASSY 05 x 108' - LR CAP END

NOTE: INSTALLATION MUST CONFORM TO GOOD SHIP PRACTICES, SAE STANDARDS, RYLA STANDARDS, AND OTHER APPLICABLE STANDARDS.

NO.	DATE	REVISION
Δ	16FEB16	CORRECTED RODD/CAP

THE INFORMATION DISCLOSED IN THIS DRAWING IS CONFIDENTIAL AND MUST NOT BE DISCLOSED OR USED IN ANY MANNER WHICH WILL BE DETRIMENTAL TO THE IAH CORPORATION

LEVELING SYSTEM: AP55493

SCALE: 1:6 DATE: 10AUG15 DRAWN BY: HWH

HYD CONN DIAGRAM

1-80 EXT 267 SOUTH  
RT 1 MOSCOW, IDWA 52760

LDS DRAWING NUMBER MP70900