


ORIENTATION
FRONT



- Ⓐ AP53032 HOSE ASSY 04 x 420' - RF RODD END
- Ⓑ AP54017 HOSE ASSY 05 x 420' - RF CAP END
- Ⓒ AP7178 HOSE ASSY 04 x 504' - LF RODD END
- Ⓓ AP25654 HOSE ASSY 05 x 504' - LF CAP END
- Ⓔ AP4162 HOSE ASSY 04 x 192' - RR RODD END
- Ⓕ AP22313 HOSE ASSY 05 x 192' - RR CAP END
- Ⓖ AP4161 HOSE ASSY 04 x 120' - LR RODD END
- Ⓗ AP7818 HOSE ASSY 05 x 120' - LR CAP END

LOCATION AND ORIENTATION OF PUMP/MANIFOLD ASSEMBLY WILL DIFFER DEPENDING UPON O.E.M.

NOTE: INSTALLATION MUST CONFORM TO GOOD SHOP PRACTICES, SAE STANDARDS, RVIA STANDARDS, AND OTHER APPLICABLE STANDARDS.

LEVELING SYSTEM: AP60533

NO.	DATE	REVISION

HWH 1-80 EXIT 267 SOUTH
 RT 1 MOSCOW, IOWA 52760
 SCALE 1:6 DATE 20SEP19 DRAWN BY
 HYD CONN DIAGRAM
 FARBER DRAWING NUMBER MP71240

THE INFORMATION DISCLOSED ON THIS DRAWING IS CONFIDENTIAL AND MUST NOT BE DISCLOSED OR USED IN ANY MANNER WHICH WILL BE DETRIMENTAL TO THE HWH CORPORATION