

- P12-P1
1. BLUE
 2. BROWN
 3. GRAY
 4. PURPLE
 5. BLACK/WHITE
 6. BLACK
 7. WHITE/BLACK
 8. WHITE
 9. ORANGE/BLACK
 10. ORANGE
 11. GREEN
 12. GREEN/BLACK
 13. RED/BLACK
 14. KEYING PIN
 15. RED

- P3
1. REAR SENSE (ORANGE)
 2. RIGHT SIDE SENSE (GREEN)
 3. FRONT SENSE (BLACK)
 4. LEFT SIDE SENSE (YELLOW)
 5. GROUND (WHITE)

- P2
1. BLK(W4000) LEFT REAR WARNING SW.
 2. BLK(W3000) RIGHT REAR WARNING SW.
 3. BLK(W2000) RIGHT FRONT WARNING SW.
 4. BLK(W1000) LEFT FRONT WARNING SW.
 5. WHT(W6235) GROUND
 6. KEY PIN
 7. RED(W6121) ACCESSORY
 8. BLK(W7699) WARNING LIGHT/BUZZER CONTROL
 9. N/C

