

- P12-P1
1. BLUE
 2. BROWN
 3. GRAY
 4. PURPLE
 5. BLACK/WHITE
 6. BLACK
 7. WHITE/BLACK
 8. WHITE
 9. ORANGE/BLACK
 10. ORANGE
 11. GREEN/BLACK
 12. GREEN
 13. RED/BLACK
 14. KEYING PIN
 15. RED

- P3
1. REAR SENSE (RED)
 2. RIGHT SIDE SENSE (GREEN)
 3. FRONT SENSE (BLACK)
 4. LEFT SIDE SENSE (YELLOW)
 5. GROUND (WHITE)

- P2
1. BLK(W4000) LEFT REAR WARNING SW.
 2. BLK(W3000) RIGHT REAR WARNING SW.
 3. BLK(W2000) RIGHT FRONT WARNING SW.
 4. BLK(W1000) LEFT FRONT WARNING SW.
 5. WHT(W6235) GROUND
 6. KEY PIN
 7. N/C
 8. BLK(W7699) WARNING LIGHT/BUZZER CONTROL
 9. N/C

