



ISSUE DATE: Jul 25, 2008

CHECK LIST

Coach Number: _____

Inspection Date: _____

Inspected By: _____

ACTIVE AIR CONNECTION CHECK LIST

Follow steps 1 through 9 recording the BAG PRESSURE readings in the chart on the back after each step is performed. Fax this form, once completed to (563) 724-3408 attn.: Marc Frerichs

1. (a) At HOME PAGE 1 press MANUAL AIR LEVEL.
(b) At MANUAL AIR LEVELING page press and hold DUMP until all air is audibly exhausted from all air bags.
(c) Press HOME located in the upper left corner of the control panel.
(d) At HOME PAGE 1 press HOME PAGE 2. At HOME PAGE 2 press BAG PRESS STATUS.
(e) Record the numbers located at the bottom of each column.
(f) Press HOME located in the upper left corner of the control panel.
2. At HOME PAGE 1 press MANUAL AIR LEVEL. At MANUAL AIR LEVELING page press and hold for approx. 25-30 seconds the left side RAISE button.
Repeat steps 1(c) through 1(f)
3. At HOME PAGE 1 press MANUAL AIR LEVEL. At MANUAL AIR LEVELING page press and hold the left side LOWER button until all air is audibly exhausted from the air bags.
Repeat steps 1(c) through 1(f)
4. At HOME PAGE 1 press MANUAL AIR LEVEL. At MANUAL AIR LEVELING page press and hold for approx. 25-30 seconds the right side RAISE button.
Repeat steps 1(c) through 1(f)
5. At HOME PAGE 1 press MANUAL AIR LEVEL. At MANUAL AIR LEVELING page press and hold the right side LOWER button until all air is audibly exhausted from the air bags.
Repeat steps 1(c) through 1(f)
6. At HOME PAGE 1 press MANUAL AIR LEVEL. At MANUAL AIR LEVELING page press and hold for approx. 25-30 seconds the front (top) RAISE button.
Repeat steps 1(c) through 1(f)
7. At HOME PAGE 1 press MANUAL AIR LEVEL. At MANUAL AIR LEVELING page press and hold the front (top) LOWER button until all air is audibly exhausted from the air bags.
Repeat steps 1(c) through 1(f)
8. At HOME PAGE 1 press MANUAL AIR LEVEL. At MANUAL AIR LEVELING page press and hold for approx. 25-30 seconds the rear (bottom) RAISE button.
Repeat steps 1(c) through 1(f)
9. At HOME PAGE 1 press MANUAL AIR LEVEL. At MANUAL AIR LEVELING page press and hold the rear (bottom) LOWER button until all air is audibly exhausted from the air bags.
Repeat steps 1(c) through 1(f)

BAG PRESSURE CHART

	L TAG	LR	LF	SYS	RF	RR	R TAG
1							
2							
3							
4							
5							
6							
7							
8							
9							