

PERFORMANCE CHECK LIST 2000 SERIES, COMPUTER-CONTROLLED AIR LEVELING SYSTEM SINGLE-STEP AIR LEVELING

| MANUFACTURER | TYPE | | DATE | | |
|---|-------------------------------|-------------|--|--|--|
| VEHICLE ID# | | INSPECTOR _ | | | |
| WARNING: DO NOT OPERATE THIS SYSTEM UNLESS FULLY INSTRUCTED ON SYSTEM SAFETY PROCEDURES. | | | | | |
| "EXCESS SLOPE" Indicator LEVELING SYSTEM ACTIVE "AIR" Button | Light cator Light (RED) | | LEFT SIDE (RAISE) Manual Button FRONT (LOWER) Manual Button FRONT (RAISE) Manual Button JACK DOWN Indicator Light (4) RED RIGHT SIDE (RAISE) Manual Button RIGHT SIDE (LOWER) Manual Button LEVEL SENSING Indicator Light (4) YELLOW REAR (RAISE) Manual Button REAR (LOWER) Manual Button LEFT SIDE (LOWER) Manual Button | | |
| LIGHTED RESET SWITCH — | MASTER WARNING LIGHT — | | TRAVEL MODE Light (GREEN) RAISE Indicator Light | | |


NOTE: WHEN CHECKING THAT AIR BAGS ARE COMPLETELY DEFLATED OR INFLATED, IS CALLED FOR, VISUALLY, OR IF NECESSARY, PHYSICALLY CHECK THE AIR BAGS.


| | OK | REWORK |
|--|-----------|--------|
| 1. POWER CONNECTION: SET PARK BRAKE. WITH THE IGNITION SWITCH OFF, PRESS THE "AIR" BUTTON. NO LIGHTS THE PANEL SHOULD BE LIT. TURN IGNITION SWITCH ON, PRESS "AIR" BUTTON. THE LEVEL SYSTEM ACTIVE LIGHT SHOULD START FLASHING. TURN IGNITION SWITCH OFF. LEVELING SYSTEM ACTIVE LIGHT SHOULD CONTINUE FLASHING. PUSH THE "CANCEL" BUTTON. THE LEVELING SYSTEM ACTIVE LIGHT SHOULD GO OUT. [COMMENTS] | LING G | |
| 2. "TRAVEL MODE" BUTTON CHECK: WITH THE ENGINE RUNNING PUSH THE "TRAVEL MODE" BUTTON. THE "TRAVEL MODE" BU THE "TRAVEL MODE" BUTTON LIGHT (RED) SHOULD FLASH THREE TIMES AND GO OUT. TH SUSPENSION SHOULD GO TO TRAVEL HEIGHT. CHECK THAT THERE ARE NO DEFLATED AI [COMMENTS] | E | |







MI15.460M 03JUN10





NOTE: THE FOLLOWING DIAGRAM MAY NOT WORK FOR ALL COACHES. MOVE RAMP LOCATIONS AS NECESSARY TO ACCOMMODATE COACHES WITH DIFFERENT WHEEL BASES.





MI15.460N 27MAY10