
INSTALLATION INSTRUCTIONS FOR REPLACEMENT PARTS WITH 2-WIRE PACKARD CONNECTORS WITH AP1403 ADAPTER WIRE

1. IF REPLACING A COMPONENT THAT HAS A 2-PIN PACKARD TOWER DISREGARD THE ADAPTOR. IT IS NOT NEEDED.
2. IF THE EXISTING COMPONENT USES A 1-PIN PACKARD TOWER TO CONNECT TO THE HARNESS, USE THE ADAPTOR AS SHOWN AND RECONNECT THE COMPONENT THE SAME AS THE ORIGINAL. MAKE SURE THE MOUNTING SURFACE FOR THE RING TERMINAL IS A SOLID, CLEAN GROUND. THE FRAME OF THE COACH IS THE BEST GROUNDING SURFACE. USE A STAR WASHER BETWEEN THE RING TERMINAL AND THE MOUNTING SURFACE. SEE ILLUSTRATION BELOW.
3. IF THE EXISTING COMPONENT DOES NOT HAVE A PACKARD TOWER USE THE ADAPTOR AS SHOWN BELOW, EXCEPT CUT THE PACKARD TOWER OFF. SPLICE THE ADAPTOR WIRE TO THE EXISTING HARNESS WITH SOLDER, AND THEN SHRINK TUBE THE SPLICE. CONNECT THE RING TERMINAL OF THE WHITE WIRE TO A SOLID, CLEAN GROUND LIKE THE FRAME AS SHOWN BELOW.

