


	AP43639 CONTROL BOX	
		RIGHT SIDE
CN1(BRDWN) PIN 1 BLK(W1400) LEFT FRONT EXTEND 2 BLK(W1500) LEFT FRONT RETRACT 3 BLK(W2400) RIGHT FRONT EXTEND 4 BLK(W2500) RIGHT FRONT RETRACT 5 BLK(W4400) LEFT REAR EXTEND 6 BLK(W4500) LEFT REAR RETRACT 7 BLK(W3500) RIGHT REAR RETRACT 9 BLK(W3500) RIGHT REAR RETRACT 9 BLK(W8600) PUMP RELAY CONTROL 10 BLK(W8600) PUMP RELAY CONTROL 11 N/C 12 N/C	4 PIN GRAY PIN 1 BLK(W6800) SW. BATTERY 2 BLK(W6800) SW. BATTERY 3 WHT(W6230) GRDUND 4 WHT(W6230) GRDUND	8 PIN BLACK (LEFT SIDE)) PIN 1 N/C 2 N/C 3 N/C 4 N/C 5 N/C 6 N/C 7 BLACK 120 Ω RESISTOR 8 BLACK 120 Ω RESISTOR
AP42640 CN3(BLACK) PIN 1 BLK(W1000) LEFT FREINT WARN. SW. 2 BLK(W1200) LEFT FREINT PRESS. SW. 3 BLK(W2000) RIGHT FREINT WARN. SW. 4 BLK(W2200) RIGHT FREINT PRESS. SW. 5 BLK(W2100) SYSTEM PRESS. SW. 6 WHT(W6235) GREUND 7 N/C 8 N/C 9 BLK(W4000) LEFT REAR WARN. SW. 10 BLK(W4200) LEFT REAR PRESS. SW. 11 BLK(W3200) RIGHT REAR PRESS. SW.	AP42640 CN2(BRDWN) PIN 1 N/C (KEY PIN) 2 N/C 3 N/C 4 N/C 5 N/C 6 (WHITE) GRDUND 7 (RED) +12V 8 N/C 9 (YELLDW) LEFT SIDE SENSE 10 (BLACK) FRONT SENSE 11 (GREEN) RIGHT SIDE SENSE 12 (ORANGE) REAR SENSE	8 PIN BLACK (RIGHT SIDE) PIN 1 N/C 2 N/C 3 BLK(W6800) SWITCHED BATT. 4 WHT(W6230) GRDUND 5 CAN SHIELD 6 N/C 7 (GREEN) CAN LDW 8 (YELLDW) CAN HI
PIN 1 PIN 1 PIN 1 PIN 1 PIN 2 PIN 4 PIN 8 PIN 12 PIN 12 NDTE: DEUTSCH PIN NUMBERS TYPICAL UNLESS OTHERWISE N	N□TED N□. DATE REVISION THE INFORMATION DISCLOSED ON THIS DRAWING IS COM	HWH I-80 EXIT 267 SOUTH RT 1 MOSCOW, IOWA 52760 SCALE 1:3 DATE 12JAN10 DRAWN BY. SYSTEM SCHEMATIC ELEC
ALLATION MUST CONFORM TO GOOD SHOP PRACTICES, SAE S, RVIA STANDARDS, AND OTHER APPLICABLE STANDARDS.	FIDENTIAL AND MUST NOT BE DISCLOSED OR USED IN AN MANNER WHICH WILL BE DETRIMENTAL TO THE HWH CORPORATIO	

NOTE: INSTALLATION MUST CONFORM TO GOOD SHOP PRACTICES, SAE STANDARDS, RVIA STANDARDS, AND OTHER APPLICABLE STANDARDS.








STANDARDS, RVIA STANDARDS, AND OTHER APPLICABLE STANDARDS.


LED #	CONNECTOR	COLOR	DESCRIPTION
LED 1	CN3 PIN 1	RED	LEFT FRONT WARN. SW.
LED 2	CN3 PIN 2	GREEN	LEFT FRONT PRESS, SW,
LED 3	CN3 PIN 3	YELLOW	RIGHT FRONT WARN. SW.
LED 4	CN3 PIN 4	RED	RIGHT FRONT PRESS. SW.
LED 5	CN3 PIN 5	GREEN	SYSTEM PRESS, SW.
LED 6	NDT USED	YELLOW	NDT USED
LED 7	NDT USED	RED	NDT USED
LED 8	NOT USED	GREEN	NDT USED
LED 9	CN3 PIN 9	YELLOW	LEFT REAR WARN, SW.

LED 10 CN3	INECTOR B PIN 10	COLOR RED	DESCRIPTION LEFT REAR PRESS, SW.
	3 PIN 10	PED	LEET DEAD DDECC CV
		KLD .	LEFT KEAK FRESS, SW.
LED 11 CN3	3 PIN 11	GREEN	RIGHT REAR WARN. SW.
LED 12 CN3	3 PIN 12	YELLOW	RIGHT REAR PRESS. SW.
LED 13 CN2	PIN 9	RED	LEFT SIDE SENSE
LED 14 CNA	2 PIN 10	GREEN	FRONT SENSE
LED 15 CN2	2 PIN 11	YELLOW	RIGHT SIDE SENSE
LED 16 CN2	2 PIN 12	RED	REAR SENSE
LED 17 NOT	APPLICABLE	RED	LINK LIGHT
LED 18 NOT	APPLICABLE	RED	POWER TO CAN MODULES



I/O MODULE

12JAN10



LED #	COLOR	FUSE #	DUTPUT	RELAY #	DESCRIPTION
LED1	YELLOW			PR1	LEFT FRONT EXTEND (COIL)
LED2	RED	FUSE 1	PIN 1	PR1	LEFT FRONT EXTEND (CONTACT)
LED3	RED	FUSE 2	PIN 2	PR2	LEFT FRONT RETRACT (CONTACT)
LED4	YELLOW			PR2	LEFT FRONT RETRACT (COIL)
LED5	YELLOW			PR3	RIGHT FRONT EXTEND (COIL)
LED6	RED	FUSE 3	PIN 3	PR3	RIGHT FRONT EXTEND (CONTACT)
LED7	RED	FUSE 4	PIN 4	PR4	RIGHT FRONT RETRACT (CONTACT)
LED8	YELLOW			PR4	RIGHT FRONT RETRACT (COIL)
LED9	YELLOW			PR5	LEFT REAR EXTEND (CDIL)
LED10	RED	FUSE 5	PIN 5	PR5	LEFT REAR EXTEND (CONTACT)
LED11	RED	FUSE 6	PIN 6	PR6	LEFT REAR RETRACT (CONTACT)
LED12	YELLOW			PR6	LEFT REAR RETRACT (COIL)
LED13	YELLOW			PR7	RIGHT REAR EXTEND (COIL)
LED14	RED	FUSE 7	PIN 7	PR7	RIGHT REAR EXTEND (CONTACT)
LED15	RED	FUSE 8	PIN 8	PR8	RIGHT REAR RETRACT (CONTACT)
LED16	YELLOW			PR8	RIGHT REAR RETRACT (COIL)
LED17	YELLOW			PR9	MASTER RELAY CONTROL (COIL)
LED18	RED	FUSE 9	PIN 9	PR9	MASTER RELAY CONTACT (CONTACT)
LED19	RED	FUSE 10	PIN 10	PR10	PUMP RELAY CONTACT (CONTACT)
LED20	YELLOW			PR10	PUMP RELAY CONTROL (COIL)

DUTPUTS

LED LAYOUT