






AP6798  
SENSING UNIT



- P3
1. BLK<W9300> DUMP
  2. BLK<W9301> TRAVEL
  3. N/C
  4. BLK<W3000> RIGHT REAR WARN SW
  5. BLK<W2000> RIGHT FRONT WARN SW.
  6. BLK<W1000> LEFT FRONT WARN SW.
  7. BLK<W4000> LEFT REAR WARN SW.
  8. N/C
  9. BLK<W7699> BUZZER/WARN CONTROL
  10. BLK<W6820> PUMP RELAY SUPPLY
  11. WHT<W6230> GROUND

- P2
1. REAR SENSE (RED)
  2. RIGHT SIDE SENSE (GREEN)
  3. FRONT SENSE (BLACK)
  4. LEFT SIDE SENSE (YELLOW)
  5. GROUND (WHITE)

- P1
1. RED LOOP
  2. RED LOOP
  3. BLK<W9000> PARK BRAKE
  4. N/C



1. WHT<W6230> GROUND
2. BLK<W7698> BUZZER/WARN CONTROL
3. BLK<W8601> PUMP RELAY CONTROL
4. BLK<W5000> CYLINDER EXTEND
5. BLK<W5100> CYLINDER RETRACT
6. RED<W6100> SW. BATTERY

1	19APR07	REDRAWN TO 1:3 SCALE
NO.	DATE	REVISION

HWH I-80 EXIT 267 SOUTH  
RT 1 MOSCOW, IOWA 52760

SCALE 1:3 DATE 15APR98 DRAWN BY .

SYSTEM SCHEMATIC ELEC

THE INFORMATION DISCLOSED ON THIS DRAWING IS CONFIDENTIAL AND MUST NOT BE DISCLOSED OR USED IN ANY MANNER WHICH WILL BE DETRIMENTAL TO THE HWH CORPORATION

DRAWING NUMBER  
MP882030

NOTE: INSTALLATION MUST CONFORM TO GOOD SHOP PRACTICES, SAE STANDARDS, RVIA STANDARDS, AND OTHER APPLICABLE STANDARDS.