


AP46464 CONTROL BOX







CN1(BROWN)

PIN

1 BLK(W1400) LEFT FRONT EXTEND

3 BLK(W2400) RIGHT FRONT EXTEND

4 N/C

5 BLK(W4400) LEFT REAR EXTEND

N/C 6

BLK(W3400) RIGHT REAR EXTEND

8 N/C

9 BLK(W8500) MASTER RELAY CONTROL

10 BLK(W8600) PUMP RELAY CONTROL

11 N/C

12 N/C

AP42640 CN3(BLACK)

1 BLK(W1000) LEFT FRONT WARN, SW.

BLK(W1200) LEFT FRONT PRESS. SW.

3 BLK(W2000) RIGHT FRONT WARN, SW.

4 BLK(W2200) RIGHT FRONT PRESS. SW.

5 BLK(W8100) 3000 LB, PRESS, SW,

6 WHT(W6235) GROUND

7 N/C

8 BLK(W8101) 50 LB. PRESS. SW.

9 BLK(W4000) LEFT REAR WARN, SW.

10 BLK(W4200) LEFT REAR PRESS, SW.

11 BLK(W3000) RIGHT REAR WARN, SW.

12 BLK(W3200) RIGHT REAR PRESS. SW.

PIN 1 -PIN 1 -PIN 1 -1000000 0 0 0 0 0 PIN 4 PIN 8 **PIN 12**

NOTE: DEUTSCH PIN NUMBERS TYPICAL UNLESS OTHERWISE NOTED

NOTE: INSTALLATION MUST CONFORM TO GOOD SHOP PRACTICES, SAE STANDARDS, RVIA STANDARDS, AND OTHER APPLICABLE STANDARDS.

4 PIN GRAY

PIN

1 BLK(W6800) SW. BATTERY

2 BLK(W6800) SW. BATTERY

4 WHT(W6230) GROUND

3 WHT(W6230) GROUND

8 PIN BLACK (LEFT SIDE))

1 N/C 5 N/C

3 N/C

4 N/C

N/C

N/C

BLACK 120 Ω RESISTOR

8 BLACK 120 Ω RESISTOR

AP42640 CN2(BRDWN)

1 N/C (KEY PIN)

5 N/C

3 N/C

4 N/C

5 N/C

6 (WHITE) GROUND

7 (RFD) +12V

8 N/C

9 (YELLOW) LEFT SIDE SENSE

10 (BLACK) FRONT SENSE

11 (GREEN) RIGHT SIDE SENSE

12 (ORANGE) REAR SENSE

8 PIN BLACK (RIGHT SIDE)

1 N/C

2 N/C

3 BLK(W6800) SWITCHED BATT.

4 WHT(W6230) GROUND

5 CAN SHIELD

N/C


7 (GREEN) CAN LOW


8 (YELLOW) CAN HI


			I-80 EXIT 267 SOUTH RT 1 MOSCOW, IOWA 52760
			SCALE 1:3 DATE 16APR10 DRAWN BY .
N□.	DATE	REVISION	SYSTEM SCHEMATIC ELEC


THE INFORMATION DISCLOSED ON THIS DRAWING IS CON-FIDENTIAL AND MUST NOT BE DISCLOSED OR USED IN ANY MANNER WHICH WILL BE DETRIMENTAL TO THE HWH CORPORATION

DRAWING NUMBER MP90461 A/F










I/O MODULE

LED #	CONNECTOR	COLOR	DESCRIPTION
LED 1	CN3 PIN 1	RED	LEFT FRONT WARN. SW.
LED 2	CN3 PIN 2	GREEN	LEFT FRONT PRESS, SW.
LED 3	CN3 PIN 3	YELLOW	RIGHT FRONT WARN, SW.
LED 4	CN3 PIN 4	RED	RIGHT FRONT PRESS. SW.
LED 5	CN3 PIN 5	GREEN	3000 LB. PRESS. SW.
LED 6	NOT USED	YELLOW	NOT USED
LED 7	NOT USED	RED	NOT USED
LED 8	CN3 PIN 8	GREEN	50 LB. PRESS. SW.
LED 9	CN3 PIN 9	YELLOW	LEFT REAR WARN, SW.
	[

LED #	CONNECTOR	COLOR	DESCRIPTION
LED 10	CN3 PIN 10	RED	LEFT REAR PRESS. SW.
LED 11	CN3 PIN 11	GREEN	RIGHT REAR WARN, SW.
LED 12	CN3 PIN 12	YELLOW	RIGHT REAR PRESS. SW.
LED 13	CN2 PIN 9	RED	LEFT SIDE SENSE
LED 14	CN2 PIN 10	GREEN	FRONT SENSE
LED 15	CN2 PIN 11	YELLOW	RIGHT SIDE SENSE
LED 16	CN2 PIN 12	RED	REAR SENSE
LED 17	NOT APPLICABLE	RED	LINK LIGHT
LED 18	NOT APPLICABLE	RED	POWER TO CAN MODULES

NOTE: INSTALLATION MUST CONFORM TO GOOD SHOP PRACTICES, SAE STANDARDS, RVIA STANDARDS, AND OTHER APPLICABLE STANDARDS.

MP90461 E 16APR10



DUTPUTS LED LAYDUT

LED #	COLOR	FUSE #	DUTPUT	RELAY #	DESCRIPTION
LED1	YELLOW			PR1	LEFT FRONT EXTEND (COIL)
LED2	RED	FUSE 1	PIN 1	PR1	LEFT FRONT EXTEND (CONTACT)
LED3	RED	FUSE 2	PIN 2	PR2	NOT USED
LED4	YELLOW			PR2	NDT USED
LED5	YELLOW			PR3	RIGHT FRONT EXTEND (COIL)
LED6	RED	FUSE 3	PIN 3	PR3	RIGHT FRONT EXTEND (CONTACT)
LED7	RED	FUSE 4	PIN 4	PR4	NOT USED
LED8	YELLOW			PR4	NOT USED
LED9	YELLOW			PR5	LEFT REAR EXTEND (COIL)
LED10	RED	FUSE 5	PIN 5	PR5	LEFT REAR EXTEND (CONTACT)
LED11	RED	FUSE 6	PIN 6	PR6	NOT USED
LED12	YELLOW			PR6	NOT USED
LED13	YELLOW			PR7	RIGHT REAR EXTEND (COIL)
LED14	RED	FUSE 7	PIN 7	PR7	RIGHT REAR EXTEND (CONTACT)
LED15	RED	FUSE 8	PIN 8	PR8	NOT USED
LED16	YELLOW			PR8	NOT USED
LED17	YELLOW			PR9	MASTER RELAY CONTROL (COIL)
LED18	RED	FUSE 9	PIN 9	PR9	MASTER RELAY CONTACT (CONTACT)
LED19	RED	FUSE 10	PIN 10	PR10	PUMP RELAY CONTACT (CONTACT)
LED20	YELLOW			PR10	PUMP RELAY CONTROL (COIL)